Repair instruction

Toilets
Cassette Toilets
C250/C260

SC lipseal
23721

A


Remove the holdingtankplate by turning it from the closed circle to the open circle on the holdingtank(45°)





B

Make sure the blade arm driver is in this position(picture)
Then unscrew the 6 screws



C

Remove the lipseal





D

After replacing the seal,follow instruction B-A.to complete the holdingtank
Note:make sure you screw crosswise for the best result(B)

