N3000 series
Australian models


spare part list

N3141

Front	2
Controls	6
Back	10

N3175/N3185

Front	4
Controls	8
Back	12




13*



LE1375_N3141_AUS_FRONT

		Spare part number	Spare part number	Colours available
1	Hinge plate top left	691111 *< 01-05-2015*	691456 *≥ 01-05-2015*	27
2	Hinge plate top right			
3	Hinge pin (including spring)			
4	Hinge plate bottom right			
5	Hinge plate bottom left			
6	Hinge pin bottom			
7	Control panel	*Refer to page 6*		
8	Cap freezer bolt (6x)	624479		08
9	Ice cube tray	Not available		
10	Internal fan	691729		
11	Freezer door		691112	
	Hinge freezer door (2x)	624680		08
12	Fin			
13	Identification label*			
14	Door lock plate		691113	
15	Door handle			
16	Shelf food retainer	691114		08
17	Shelf 340 x 182	691115		08
18	Clip shelf small	623626		08
19	Clip shelf large	623625		08
20	Shelf 340 x 241	691116		08
21	Cap (2x)	623622		08
22	Fin clip (3x)	623059		
23	Thermistor	623077		
24	Guiding cover	691118		08
25	Slide-out box	691119		08, 12
26	Shelf 340 x 268	691117		08
27	Divider bar	Not available		
28	Drawer handle	691287		27
29	Drawer divider	691120		12
30	Drawer guides	691123		
31	Drawer bin	691288		08
32	Drawer door	690521		27R
33	Cabinet door	690519		27R
34	Door bin	691121		12
35	Drip tray	691885		08
NA	Clip - door conversion (2x)	691127		

* With a request for information or service, always provide the serial number of the refrigerator. The serial number is the code below the barcode on the identification label.



18*



LE1142_N3185Z-front_0215-V03

			Spare part number		Colours
1	Latch		*< 24-04-2018 < (E114V……)* 62698527 ** *(framed & frameless door)*	*≥ 24-04-2018 ≥ (E114V……)* 62698527 ** *(framed door)* 69173927 ** *(frameless door)*	
2	Storage strap (2x)	626986			
3	Strike plate				
4	Pocket cover				
5	Center hinge		635011		
6	Hinge plate				
7	Hinge plate				
8	Cap (2x)	623622			08
9	Cap freezer bolt (6x)	624479			08
10	Shelf 404 x 238.5	690843			08
11	Ice cube tray				
12	Control panel	*refer to page 8*			
13	Fin				
14	Shelf 428.4 x 232.3	691191			08
15	Clip shelf large	623625			08
16	Fin clip	623059			
17	Thermistor	623077			
18	Identification label *				
19	Shelf 428.4 x 282.3		691192		08
20	Shelf lock screw				
21	Clip shelf large	623625			08
22	Vegetable bin	626980			12
23	Shelf food retainer	691188			08
24	Latch bottom	624001			27
25	Door bin	626976			12
26	Bottle retainer	626989			12
27	Door bin	626977			12
28	Door Curved Framed (black)	635032			27R
	Door Curved Frameless (Piano black)	690153			138R
29	Freezer Door Curved Framed (black)	690113			27R
	Freezer Door Curved Frameless (Piano black)	690154			138R
30	Door panel freezer door 270 x 463 x 1.2	691455SP			
31	Door panel 863 x 464 x 1.2	691454SP			

* With a request for information or service, always provide the serial number of the refrigerator. The serial number is the code below the barcode on the identification label.


**

62698527



69173927





*18



LE1142-N3185-front_1018

		Spare part number	Spare part number	Spare part number	Colours available
1	Latch		62698527 ** *(framed door)*	69173927 ** *(frameless door)*	
2	Storage strap (2x)	626986			
3	Strike plate				
4	Pocket cover				
5	Center hinge		635011		
6	Hinge plate				
7	Hinge plate				
8	Cap (2x)	623622			08
9	Cap freezer bolt (6x)	624479			08
10	Shelf 404 x 238.5	690843			08
11	Ice cube tray				
12	Control panel	*refer to page 8*			
13	Fin				
14	Shelf rack 415 x 200	692511			144
	Clip shelf rack large	692514			08
	Clip rack safety lock	692515			08
15	Food retainer	692516			08
16	Fin clip	623059			
17	Thermistor	623077			
18	Identification label *				
19	Shelf rack 415 x 250	692512			144
21	Clip shelf rack large	692514			08
22	Clip rack safety lock	692515			08
23	Vegetable bin reversible	692524			144
24	Latch bottom	624001			27
25	Door bin	692520			144
26	Bottle retainer	692521			08
27	Door Curved Framed (black)	635032			27R
	Door Curved Frameless (Piano black)	690153			138R
28	Freezer Door Curved Framed (black)	692371			27R
	Freezer Door Curved Frameless (Piano black)	692372			138R

* With a request for information or service, always provide the serial number of the refrigerator. The serial number is the code below the barcode on the identification label.


**

62698527



69173927





LE1387_N3141_US_Controls


		Spare part number	Spare part number	Spare part number	Colours available
1	Technical panel flat [1]	691102			
2	Screws				
3	Housing flat [1]		691104		27
4	Screws				
5	PCB LCD DM		~~691108~~ 692233 *LED version*[2]		
6	Sticker LCD	~~691452~~			

[1] ~~Order also spare part 'Sticker LCD' (#6) with this spare part number~~

[2] *LED version kit* contains:

- PCB LED display module
- Sticker LED
- Overlay LED

~~Xxxxx~~ = not available anymore



LE1143_Control Panel-curved525Z_0914-V01


		Spare part number	Spare part number	Colours available
1	Technical panel curved[1]	690825		
2	Screws			
3	PCB LED DM[1]	~~691103~~ 692233 *LED version*[2]		
4	Housing curved[1]	691185 *left hinged version*	691186 *right hinged version*	27
5	Screws			
6	Overlay LED[1]	691105		
7	Sticker LED	691106		
8	Battery hatch			
	Battery pack	690225		27
9	Rocker Switch	691187		

[1] Order also spare part number 691106 (#7) with this spare part number

[2] *LED version kit* contains:


- PCB LED display module
- Sticker LED
- Overlay LED

~~Xxxxx~~ is not available anymore



LE1377_N3141_AUS_BACK

		Spare part number	Spare part number	Colours available
1	Heat cap	690839		
2	Heat diffuser	Not available		
3	Heater AC 240VAC/300W	691193		
4	Heater DC 12VDC/205W	691125	(replacement 690875)	
5	Heater box	Not available		
6	Burner assembly	690861		
7	Spark electrode	690840		
8	Power control board	692248		
9	Gas valve	691195		
10	Gas pipe	Not available		
11	Thermistor cable		690853 *incl. connectors*	
	Loose connector temperature *power board side*	690855		
12	Communication cable		691194 *incl. connectors*	
	Loose connector communication	690856		
13	Bracket Fan	690865		
14	Fan 1x			
15	Fan extension cable	691727		
16	Bracket Fan	690865		
17	Fan 1x			
18	Thermostat dc fan 90°	691728		
19	Thermostat dc fan	690866		


1
2
15
14
13
3
4
5
12
11
8
9
10
6
7

		Spare part number	Spare part number	Colours available
1	Heat cap			
2	Heat diffuser			
3	Heater 240VAC/300W	691193		
4	Heater 12VDC/205W	691125	(replacement 690875)	
5	Heater box			
6	Burner assembly	690861		
7	Spark electrode	690840		
8	Power control board	692248		
9	Gas valve	691195		
10	Gas pipe			
11	Thermistor cable		690853 *incl. connectors*	
	Loose connector temperature *power board side*	690855		
12	Communication cable		691194 *incl. connectors*	
	Loose connector communication	690856		
13	Cable Fan			
14	Bracket Fan 1x	690865		
15	Fan 1x			

Colour Numbers	Description	Colour reference
07	Traffic Grey	RAL 7042
08	White	MP 1013 MP FR 85 R7
12	Blue	RAL 5012
27(R)	Black	RAL 9005
30	Mocha	NCS S 2005-Y40R
90	Anthracite Grey	RAL 7016
136	Black Grey	RAL 7021
138R	Piano Black	AM50CI EG schwarz 8325 VA 82-99139/10